

Installation Instructions #3030P
JLT 3.0 Oil Separator, Passenger Side
(2015-17 Mustang GT with Whipple Supercharger)

Please review complete instructions prior to installing.

1 Remove the stock line from the valve cover to supercharger

1

2 Use supplied bolt and nut to attach JLT Bracket to the mounting tab behind the passenger side headlight shown here:




2

3 Use the M4x10 screws to attach JLT Separator to the JLT Bracket. Route long hose down and up along the wire harness. Plug on to the fitting on the supercharger and plug the short hose on to the fitting on the valve cover.



3



To properly clean the filter in the Oil Separator spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thanks for the business. If you have any questions, please e-mail info@JLTtruecoldair.com or call 757-335-1940. Our hours are Monday-Friday, 8:00am – 5:00pm Eastern Time.

Warranty: JLT Performance Inc. will repair or replace any part of their product found upon our inspection to be defective in workmanship or material within 1 year from the purchase date for the original purchaser.

Disclaimer: JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLTtruecoldair.com for complete return policy.