

PART #4339 05-08 MUSTANG 500 CHIN SPOILER

Notice: Prefit Before Painting. Install new, unpainted parts according to these instructions. Then remove parts, paint them and re-install.

Painted or Altered Parts are Non-Refundable

Pre-fitting the chin spoiler: This chin spoiler is designed to directly fit over the existing factory GT bumper cover. Remove the 2 screws in the left and the right front wheel wells that attach the plastic inner wheel well to the front bumper. Remove the 4 screws under the car that attach the front bumper to the plastic shield. Hold the chin spoiler in place on the front bumper and reinstall the factory screws. Use a drill with a phillips bit to install the provided screws into the bumper through the pre-drilled holes in the chin spoiler. (The silver screws are designed to thread themselves into the bumper without pre-drilling the holes) **As shown in figure A & B.**

Fig. A




Fig. B



PAINTING INSTRUCTIONS

VERY IMPORTANT: The following painting procedures MUST be followed EXACTLY

1. To remove any mold release contaminants, clean the back of the part first. Using 2 new clean rags, saturate the first rag with plastic prep cleaner* and begin cleaning. Then use the second rag to remove the prep cleaner. Continuously fold both rags to their clean sides during the process. Use 3 sets of new rags throughout the process. This prevents mold release contaminants from transferring to the painted surface.
2. Repeat step one on the front of the part.
3. Rinse the part with water. Apply a generous amount of Ajax® or sand fix* to a red scuff pad* (3M Scotch Brite Brand) and scrub the surface to be painted THOROUGHLY (especially where the 2-sided tape is installed, on the back side of the part, and all the hard to reach areas). Then rinse with water and dry. The scrubbed surface should be dull. If any shiny spots show, repeat the process on those areas.
4. Using another set of clean new rags, again clean the surface to be painted with plastic prep cleaner.
5. Spray the surface to be painted with adhesion promoter* including the areas where the 2-sided tape is installed (follow the instructions on the can for application and drying time).
6. Apply 3 to 4 coats of urethane primer* with flex additive* (follow the instructions on the can for application and drying time).
7. Wet sand primer with 600 grit sandpaper. Be careful not to sand through the primer. If you do, you MUST clean those areas with plastic prep cleaner, apply adhesion promoter and prime. Once the primer has dried, wet sand the areas that were touched up. Your surface is now ready for paint.

* These items can be purchased at any auto body supply store.

PART #4339		
QTY	DESCRIPTION	HARDWARE #
7	SILVER PHILIPS SCREWS	32144

