



INSTALLATION INSTRUCTIONS

MAKE: FORD
MODEL: MUSTANG
YEAR: 2005-2009
ENGINE: V6-4.0L

**Axle-Back Exhaust
Stainless Steel
49-43048**

aFe recommends professional installation on our products.



2.5" Band Clamp

05-41061

Tail Pipe

05-44751

Caution: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation.

Step 1: (Read Instructions prior to installation) Secure vehicle on jack stands (Refer to your manual for specified jack stand positions).

Step 2: Loosen stock muffler band clamp.

Step 3: Remove the (x3) muffler rubber hanger mounts off chassis and remove stock muffler section.

Step 4: Slide the rubber hanger mounts off the stock muffler and install onto the aFe Axle-Back Muffler.

Step 5: Using (x1) supplied 2.5" aFe band clamp, slide the aFe muffler onto the stock mid pipe until the aFe muffler pipe bottoms out on the stock mid pipe stand off nut.

Step 6: Align the Axle-Back muffler and then tighten the band clamp from step 5.

Step 7: Re-check all your work. Check system and retighten after 150 miles.

Note: It is normal for your exhaust system to emit smoke for the first few minutes upon initial start-up due to grease used in the mandrel bending process.

Thank you for choosing aFe Power!