



Mustang Master Cylinder Kit Installation

- 1) Disconnect cable from Quadrant under dash.
- 2) Remove Quadrant and replace with the Quadrant in kit.
- 3) After disconnecting cable from both ends, remove and discard.
- 4) Install new Firewall adjuster with min 2 screws. (note: flat side goes against the seam).
- 5) Install Master Cylinder with cable thru adjuster and connect cable end to the Quadrant under dash.
- 6) Screw Adjuster out until Master Cylinder Nose is just seated into Firewall Adjuster pocket.
- 7) Mount remote Reservoir to Shock Tower and route red rubber hose from M/C to Reservoir.
- 8) Install Slave Cylinder from kit.
- 9) Connect AN 4 steel braided line from Master Cylinder to Slave Cylinder, (Internal or External) and bleed system.
- 10) After all air is bled out, the Firewall adjuster can be used to adjust desired clutch engagement.

