



**AMERICAN CAR CRAFT INSTRUCTIONS**  
**MUSTANG GT 5.0 2011-2012 MASTER CYLINDER COVER**  
**w/PERFORATED CAP**  
**PART #273016** patent pending



**PARTS INCLUDED:**

- 1-Stainless Master Cylinder Cover
- 1-Perforated Cap Cover
- 1-Adhesive Promoter Pack

**Introduction:** This new ACC design is a truly custom look for the new mustang. It will require very little preparation and should take just a few minutes to install.

**Liner Information:** Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

1. Peel the protective liner from the body of your new stainless cover.
2. Remove the factory master cylinder cap and then set the new cover in place over the factory reservoir. Then replace the factory cap.
3. Scrub clean the top of the factory cap with alcohol to remove any dirt then swipe the cap with the adhesive promoter provided. This chemical is NOT a cleaner but an adhesive accelerator and must be used in order to expect a good long term bond.
4. Remove the Velcro half inside the decorative chrome cap provided and then peel the release liner and press it to the factory cap. Then simply press the decorative cap in place to finish the installation.

**Thank you and enjoy your purchase!**

**If any questions occur during installation please contact**

**AMERICAN CAR CRAFT**

**18924 SAKERA ROAD-HUDSON FLORIDA 34667**

**Phone # 727-861-1500 Fax # 727-861-1520**

**[www.americancarcraft.com](http://www.americancarcraft.com)**