



CHIN SPOILER

(2015-2017 MUSTANG EXCL. PERFORMANCE PACK)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Left
- (1) Center
- (1) Right
- (15) Large Screws
- (4) Small Screws

TOOLS REQUIRED

Phillips Head Screw Driver

STEP 1

Begin by assembling the (3) sections of the chin spoiler. Using (1) small screw on each side of the center section, attach the outer portions of the chin spoiler to the center section.

STEP 2

Raise and support the front of the vehicle to allow better access to the under side of the front bumper. With a helper, align the chin spoiler to the factory chin spoiler **Note: this chin spoiler will not work on performance pack equipped vehicles. Using the provided screws, screw the new chin spoiler to the vehicle.



STEP 3

Installation is now complete.