



---

# CHIN SPOILER

(2018-2020 MUSTANG W/O PERFORMANCE PACK)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) Left Side
- (1) Right Side
- (1) Center
- (15) Large Phillips Screws
- (4) Small Phillips Screws

### TOOLS REQUIRED

---

- Drill
- Phillips Screw Bit

SKU # 412068

**STEP 1**



Assemble the chin spoiler by attaching both sides to the center section using the provided small Phillips head screws.

**STEP 2**



With a helper, align the chin spoiler to the front bumper. Using a screw-gun, attach the chin spoiler to the bumper using the provided (12) Phillips screws.



---

**STEP 3**

Installation is now complete.