

ALTERUM

INTERIOR TRIM

(UNIVERSAL FITMENT)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Trim Panel/Kit

TOOLS REQUIRED

Isopropyl Alcohol
Microfiber Cloth

ALTERUM



STEP 1

Clean the designated area using isopropyl alcohol and a microfiber cloth.



STEP 2

Once the area is clean and dry, peel back the double sided tape on the trim panel. Firmly adhere the trim panel to the vehicle.

Installation is now complete.