



# PRECISION MOLDED FLOOR LINERS

(2010 MUSTANG)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) LH Front Floor Liner  
(1) RH Front Floor Liner

### TOOLS REQUIRED

---

Vacuum Cleaner

SKU # 430919



---

**STEP 1**



Remove any existing floor mat from the vehicle. Clean the vehicle carpet using a vacuum cleaner.

---

**STEP 2**



Align the floor liner to the vehicle floor and press into place. If applicable, align the vehicle floor hooks into the floor liner mounting holes.

Repeat steps 1-2 for the remaining vehicle floor liners. Installation is now complete.