



PRECISION MOLDED FLOOR LINERS

(2010 MUSTANG)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner
- (1) LH Rear Floor Liner
- (1) RH Rear Floor Liner

TOOLS REQUIRED

Vacuum Cleaner

SKU # 430918



STEP 1



Remove any existing floor mat from the vehicle. Clean the vehicle carpet using a vacuum cleaner.

STEP 2



Align the floor liner to the vehicle floor and press into place. If applicable, align the vehicle floor hooks into the floor liner mounting holes.

Repeat steps 1-2 for the remaining vehicle floor liners. Installation is now complete.