



SIDE SCOOPS WITH INSERTS

(2010-2014 MUSTANG)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Side Scoop
- (1) RH Side Scoop
- (1) LH Scoop Insert
- (1) RH Scoop Insert
- (1) Roll of Double Sided Tape
- (4) Alcohol Prep Pads
- (4) Adhesion Promoter Prep Pads

TOOLS REQUIRED

- Isopropyl Alcohol
- Microfiber
- Scissors/Razor Knife

SKU # 434699

**STEP 1**

Wipe down the edges on the reverse side of the side scoop with the included Adhesion Promoter as shown.

**STEP 2**

Cut the included double sided tape to length, and apply the tape to the side scoop. Ensure the tape is layed down smooth to ensure an even adhesion surface on the vehicle.

Then, peel the tape backing from the scoop to fit the scoop insert, and adhere the insert to the scoop. Apply new tape to the top of the insert.



STEP 3

Clean the vehicle body using (1) alcohol prep pad and allow to fully dry. Then, clean the area using (1) adhesion promoter prep pad and allow to fully dry.

Familiarize the vehicle body lines behind the vehicle door. The scoop will fit around the body line.



STEP 4

Peel the red tape backing from the side scoop, and align the scoop to the vehicle approximately 1/4" away from the door. Firmly press the scoop into place to ensure proper adhesion.

Repeat steps 1-4 for the remaining side scoop. Installation is now complete.