



**Important Notice:** UVS100® Custom Sunscreens do not cover the entire glass area on some vehicles. Windshield pillar post size and angle, rearview mirror shape and size, and additional sensors can prevent some Sunscreens from providing total blackout coverage.

**HOW TO INSTALL****OPEN SUNSCREEN**

1. Unfold your UVS100® UVS Premier Series Custom Sunscreen with the reflective side facing outward.
2. Place it as flat as possible onto the dash area.
3. If there are assist handles on the windshield pillars, make sure the sunscreen fits in front of them.
4. Slide the sunscreen forward until it reaches the bottom of the windshield ahead of the defroster vents.

**PLACE IN WINDSHIELD**

1. With both hands, lift the top of the UVS100® UVS Premier Series Custom Sunscreen into the windshield area.
2. Be careful to not bend the corners while installing, as damage to the inner insulator may occur.

**SECURE IN PLACE**

1. Pull down each visor to hold the UVS100® UVS Premier Series Custom Sunscreen in place.
2. In some cases, the sunscreen may not reach all the way to the windshield pillars. This additional space is necessary to be able to install the sunscreen without damaging it.

**HOW TO REMOVE**

Simply reverse the installation steps, fold the unit and store in the trunk or under a seat.



**SCAN  
TO SEE  
DETAILED  
INSTALL  
VIDEO**

If you encounter any problems during the installation of your sunscreen, please contact our customer service department: Monday-Friday, 9AM-7PM (EST) at **800-274-7006** or by e-mail at **sales@covercraft.com**. You may also access help videos on the web at **covercraft.com**.