



---

# GT STYLE HOOD SCOOP

(2024+ MUSTANG ECOBOOST)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Hood Scoop  
(1) Roll of Double Sided Tape

### TOOLS REQUIRED

---

Exterior Detailer  
Isopropyl Alcohol  
Microfiber Cloth



---

**STEP 1**

Clean the vehicle hood with exterior detailer and a microfiber cloth to remove any dirt/debris from the hood. Then, carefully test fit the hood scoop to the vehicle to familiarize the fitment location on the vehicle.

Once familiar with the fitment, clean the hood scoop section of the hood using isopropyl alcohol and a microfiber cloth, and allow to fully dry.



---

**STEP 2**

Place the hood scoop face down on a soft surface. Clean the perimeter of the hood scoop using isopropyl alcohol, and allow to fully dry. Then, apply the included double sided tape onto the perimeter of the hood scoop. Press the tape firmly after installed to the hood scoop to ensure proper adhesion.



---

**STEP 3**

Peel the red tape backing from the double sided tape, and align the hood scoop into the vehicle hood. Once aligned, fit the hood scoop to the vehicle hood. Apply firm and even pressure to the hood scoop to ensure proper adhesion to add sides of the scoop.

Installation is now complete.