



SMOKED SIDE MARKER LIGHT COVER SET

(2024+ MUSTANG)

INSTALLATION INSTRUCTIONS

CONTENTS

(2) LH Side Marker Covers
(2) RH Side Marker Covers
(4) Alcohol Prep Pads

TOOLS REQUIRED

N/A

SKU # 443984

STEP 1

Clean the vehicle side marker light using isopropyl alcohol and a microfiber cloth. Allow the side marker light to fully dry after cleaning.

Test fit the light cover to the vehicle to familiarize fitment. Once familiar with fitment, remove the red tape backing from the side marker light cover tape.

STEP 2

Firmly press the marker light cover onto the vehicle tail light to engage the double sided tape.

Repeat steps 1-2 for the remaining light covers.

Installation is now complete.