



CARBON FIBER 3-PIECE CHIN SPOILER

(2024+ MUSTANG)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Side Spoiler Panel
(1) RH Side Spoiler Panel
(1) Center Spoiler Panel
(14) 15mm Phillips Screws
(2) Alcohol Prep Pads

TOOLS REQUIRED

Drill
Phillips Screw Bit



STEP 1

Loosely assemble the spoiler together using the double sided tape attached to the LH and RH spoiler panels. Clean the bottom-side of the center spoiler panel using the (2) alcohol prep pads to prepare for the tape.

Once clean and dry, peel the red tape backing and adhere the LH and RH spoiler panels to the center panel.



STEP 2

With a helper, align the chin spoiler to the front bumper. Ensure each side of the spoiler is even and familiarize fitment.

Using a screw-gun, attach the chin spoiler to the bumper using the provided (14) Phillips screws through the pre-drilled holes in the spoiler panels.



STEP 3

Installation is now complete.