



---

# CARBON FIBER MIRROR COVERS

(2015-2024+ MUSTANG - WITH MIRROR TURN SIGNALS)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

- (1) LH Mirror Cover
- (1) RH Mirror Cover
- (2) Alcohol Prep Pads
- (2) Adhesion Promoter Prep Pads

### TOOLS REQUIRED

---

N/A



---

**STEP 1**

Clean the vehicle mirror in the indicated area above using (1) alcohol prep pad, and allow to fully dry. Then, clean the same area using (1) adhesion promoter prep pad and allow to fully dry.

Before removing the tape backing, test fit the product to the vehicle bumper to familiarize fitment.



---

**STEP 2**

Peel the tape backing from the mirror cover, and firmly press the cover to the vehicle mirror. Apply firm and even pressure to ensure proper adhesion.

Repeat steps 1-2 for the remaining mirror cover.

Installation is now complete.