



CARBON FIBER REAR SPOILER

(2024+ MUSTANG)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Rear Spoiler
- (2) Alcohol Prep Pads
- (2) Adhesion Promoter Prep Pads

TOOLS REQUIRED

- 10mm Socket
- Ratchet
- Plastic Pry Tool
- Heat Gun
- Exterior Detailer
- Microfiber Cloth

SKU # 460347
Edited: 11/14/2024



STEP 1

Open the vehicle trunk. Remove the rubber grommets from each end of the trunk lid to reveal the spoiler mounting bolts. Remove the (2) 10mm bolts.



STEP 2

Using a plastic pry tool and a heat gun, heat the spoiler edges to loosen the adhesive and gently pry upwards to disengage the spoiler tape adhesive from the trunk lid.

STEP 3

Clean the vehicle trunk lid using exterior detailer and a microfiber cloth, and allow to fully dry.

Then, clean the outer perimeter of the trunk panel using (2) alcohol prep pad. Once fully dry, clean the same area with (2) adhesion promoter prep pad.

Test fit the spoiler to the vehicle before removing the tape backing to familiarize fitment.

STEP 4

Once familiar with the spoiler fitment, peel the red tape backing from the double sided tape and fit the spoiler to the vehicle. Apply firm, even pressure across the spoiler to encourage adhesion.

It is recommended to leave the vehicle in a dry area for 24 hours before driving to ensure proper spoiler adhesion.

Installation is now complete.