

CENTER DASHBOARD TRIM

(2015-2023 MUSTANG WITH 8" SCREEN)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Trim Panel
- (2) Alcohol Prep Pads
- (2) Adhesion Promoter Prep Pads

TOOLS REQUIRED

Interior Detailer Microfiber Cloth





STEP 1

Using interior detailer and a microfiber cloth, clean the vehicle radio / HVAC controls to remove any large dust/debris.

Clean the same area with the included alcohol prep pads, followed by the included adhesion promoter prep pads. Ensure each cleaning product is fully dry before applying the next prep product.



STEP 2

Test fit the trim panel before removing the tape backing to familiarize fitment. Once familiar, peel the white tape backing from the double sided tape pre-installed to the trim panel. Once all the tape backing is removed, align and press the trim panel to the vehicle radio / HVAC controls. Apply firm even pressure to the trim panel to encourage tape adhesion.

Installation is now complete.