

1979-2010 Billet Shift Knob Installation

Lock Nut Instructions.



1. Remove the factory shift knob by simply unscrewing it counter-clockwise.



2. Install the supplied lock nut on the shift stick.



3. Install the new shift knob by simply screwing it on by turning it clockwise. Tighten the locking nut to secure the shift knob in place.

Allen Key & Set Screw Instructions.



1. Remove the factory shifter knob by simply unscrewing it counter-clockwise.



2. Install the new shift knob to the desired location and lock in place with supplied set screw and allen key.



3. Installation complete.

05-10 Shift Knobs

Slide provided delrin boot retainer down shift handle. Slip leather boot up over lower ridge of retainer and position it to center groove. Tighten with provided set screws and allen key.

