

SPEEDFORM

TAIL LIGHT BORDER TRIM

(2024-2025+ MUSTANG)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) LH Tail Light Trim
(1) RH Tail Light Trim
(2) Alcohol Prep Pads
(2) Adhesion Promoter Prep Pads

TOOLS REQUIRED

Exterior Detailer
Microfiber Cloth

SKU # 467023
Edited: 05/21/2025

SPEEDFORM

STEP 1



- Clean the tail light using exterior detailer and a microfiber cloth, allow to fully dry.
- Clean the tail light using the included (1) alcohol prep pad, allow to fully dry.
- Clean the tail light using the included (1) adhesion promoter prep pad, allow to fully dry.

Before removing the tape backing, test fit the tail light trim panel to the tail light to familiarize fitment.

STEP 2



Peel the red tape backing from the tail light trim panel, and firmly press the panel to the vehicle tail light.

Repeat Steps 1-2 for the remaining tail light trim panel.

Installation is now complete.