

SPEEDFORM

REVERSE LIGHT TRIM

(2024-2025+ MUSTANG)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Reverse Light Trim
(1) Alcohol Prep Pads
(1) Adhesion Promoter Prep Pads

TOOLS REQUIRED

Exterior Detailer
Microfiber Cloth

SKU # 467025

SPEEDFORM



STEP 1

- Clean the rear bumper around the reverse lamp using exterior detailer and a microfiber cloth, allow to fully dry.
- Clean the rear bumper around the reverse lamp using the included (1) alcohol prep pad, allow to fully dry.
- Clean the rear bumper around the reverse lamp using the included (1) adhesion promoter prep pad, allow to fully dry.

Before removing the tape backing, test fit the trim panel to the bumper to familiarize fitment.



STEP 2

Peel the red tape backing from the reverse lamp trim panel, and firmly press the panel to the vehicle bumper.

Installation is now complete.