

SPEEDFORM

FRONT BUMPER TRIM

(2024+ MUSTANG - EXCLUDING DARK HORSE)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Bumper Trim
- (1) RH Bumper Trim
- (2) Alcohol Prep Pads
- (2) Adhesion Promoter Prep Pads

TOOLS REQUIRED

- Exterior Detailer
- Microfiber Cloth

SKU # 467028

SPEEDFORM

STEP 1



- Clean the bumper using exterior detailer and a microfiber cloth, allow to fully dry.
- Clean the bumper using the included (1) alcohol prep pad, allow to fully dry.
- Clean the bumper using the included (1) adhesion promoter prep pad, allow to fully dry.

Before removing the tape backing, test fit the bumper trim panel to the bumper to familiarize fitment. The fins will fit to the black trim and the panel will cover the vehicle body line.

STEP 2



Peel the red tape backing from the bumper trim panel, and firmly press the panel to the vehicle bumper.

Repeat Steps 1-2 for the remaining bumper trim panel.

Installation is now complete.