



PRECISION MOLDED FLOOR LINERS

(2016-2022+ CAMARO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner

TOOLS REQUIRED

Vacuum Cleaner

SKU # CC15462



STEP 1



Remove any current floor mat/liner from the vehicle. Ensure the floor is clean of any dirt/debris.

STEP 2



Apply the front floor liner to the vehicle. Secure the circular cutouts in the liner with the mounts on the floor (If applicable). Repeat this procedure for the remaining front floor liner.

Installation is now complete.