



PRECISION MOLDED FLOOR LINERS

(2016-2022+ CAMARO)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Floor Liner
- (1) RH Front Floor Liner
- (1) LH Rear Floor Liner
- (1) RH Rear Floor Liner

TOOLS REQUIRED

Vacuum Cleaner

SKU # CC15463



**STEP 1
(FRONT)**



Remove any current floor mat/liner from the vehicle. Ensure the floor is clean of any dirt/debris.

**STEP 2
(FRONT)**



Apply the front floor liner to the vehicle. Secure the circular cutouts in the liner with the mounts on the floor (if applicable). Repeat this procedure for the remaining front floor liner.



**STEP 3
(REAR)**

Remove any current floor mat/liner from the vehicle. Ensure the floor is clean of any dirt/debris.

Tuck the front portion of the liner under the vehicle seat, then press the rear portion downwards to fit flush with the vehicle floor.

Installation is now complete.