

This module will allow the GM vehicle equipped with a VATS system to be started if the pass-key or ignition contacts fail to function.

Installation

- 1. Disconnect the negative battery cable.**
- 2. Remove the lower trim panel directly under the steering column.**
- 3. Find the small black plastic male/female connector along the steering column, it will have two small black wires going into the female connector side and most likely have a brown and yellow wire coming from the male connector side. The colors of the male connector may be different due to year and model. UNPLUG THIS CONNECTOR.**
- 4. Plug the black small female connector on you new VATS MODULE into the male connector that has the brown and yellow wires going to it. Use the Velcro tape provided to attach the VATS MODULE to an appropriate place on the steering column. Done and Done, replace the trim panel and negative battery cable.**

PLEASE REMEMBER THIS MODULE BYPASSES YOUR VEHICLE ENGINE LOCK OUT ANTI THEFT FEATURE.