



1

Wash each rear quarter window with soap and water. Allow the area to dry. **Recommended: Wipe the edges of the rear quarter windows glass with isopropyl alcohol to ensure the cleanest surface possible.



3

It's recommended to start the placement with the back corner point of the window and scoop, slowly pushing the whole scoop into place from back to front.



2

Apply the supplied 3M tape to each window scoop. Test fit on each window to familiarize yourself with how they fit. Once you are comfortable with how the scoops fit, remove the 3M tape backing from one of the scoops.



4

Apply firm even pressure to all taped edges to ensure proper adhesion. Repeat steps 2 through 4 to complete installation of the other scoop.