

## **SHIFT KNOB COVER**

(2016-2023 CAMARO - WITH AUTOMATIC TRANSMISSION)

**INSTALLATION INSTRUCTIONS** 

## **CONTENTS**

- (1) Shift Knob Cover
- (1) Adhesion Promoter Prep Pad
- (1) Alcohol Prep Pad

## **TOOLS REQUIRED**

N/A



STEP 1

Clean the vehicle shift knob using the (1) alcohol prep pad, and allow to dry. Then, clean the vehicle using the (1) adhesion promoter prep pad, allow to dry.



STEP 2

Peel the white tape backing from the shift knob cover, and fit the bottom of the knob cover to the base of the vehicle shift knob. Then, hinge the top of the cover over the shift knob and firmly press into place.

Installation is now complete.