



CARBON HOOD VENT TRIM

(2016-2018 CAMARO SS)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Hood Vent Trim
- (1) RH Hood Vent Trim
- (1) Roll of Double Sided Tape

TOOLS REQUIRED

- Isopropyl Alcohol
- Microfiber Cloth
- Scissors/Razor Knife

SKU # CC20833



STEP 1

Place the new vent trim panels on a soft surface, and turn over to reveal the bottom side of the vent trim. Clean the bottom of each vent using isopropyl alcohol and a microfiber cloth and allow to fully dry. Then, use the double sided tape around the perimeter of the vent trim.

Note: Ensure tape is flat when fitted to ensure proper fitment to the vehicle later.



STEP 2

Clean the vehicle hood vent using isopropyl alcohol and a microfiber cloth, and allow to fully dry.



STEP 3

With the hood vent dry, peel the red tape backing from the vent, and align the hood vent trim to the vehicle. Once aligned, firmly press into place to ensure proper adhesion.

Repeat steps 1-3 for the remaining hood vent. Installation is now complete.