



STAINLESS STEEL PEDAL COVERS

(2016-2023 CAMARO - WITH AUTOMATIC TRANSMISSION)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Brake Pedal Cover
(1) Throttle Pedal Cover

TOOLS REQUIRED

Heat Gun (Optional)

SKU # CC20834

**STEP 1
(THROTTLE)**



Fit the throttle pedal cover over the top of the throttle pedal, and slide the cover downwards on the pedal assembly.

**STEP 2
(THROTTLE)**



Ensure both sides of the cover are properly seated onto the throttle pedal assembly.

Throttle pedal cover installation is complete.

**STEP 3
(BRAKE)**

Grab the edge of the brake pedal to remove the rubber cover from the brake pedal assembly. Use a heat gun if necessary to give the rubber additional flexibility.

**STEP 4
(BRAKE)**

Fit the brake pedal cover onto the brake pedal assembly, starting with the RH side of the brake pedal. Then, work the rubber lip around the metal brake pedal. Ensure the cover is fully seated around the pedal. Use a heat gun if necessary to give the rubber additional flexibility.

Installation is now complete.