



---

# STRUT TOWER BRACE

(2008-2023 CHALLENGER; EXCL 6.2L, & Shaker Hoods)  
(2015-2023 CHARGER)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Strut Tower Brace  
(6) M8 x 1.25 Flange Nuts  
(6) M8 Flat Washers

### TOOLS REQUIRED

---

13mm Deep Socket  
Ratchet  
Floor Jack



## STEP 1



Open the vehicle hood. Remove the OEM strut covers, if equipped. Remove the engine cover (5.7L). Remove (6) 13mm upper strut nuts.

## STEP 2



Fit the strut tower brace to the vehicle strut studs. Once fitted, use the included (6) M8 Flat washers and (6) M8 flange nuts to secure the brace to the vehicle.

**Note:** If the strut studs do not align with the strut brace initially, use a floor jack and slightly lift the vehicle to relieve strut tension. Then, push/pull the strut studs to better align with the brace.



---

### STEP 3



Torque the strut nuts evenly to 20 ft. lbs. Installation is now complete.

Note: Some vehicles have close A/C line and EVAP line clearance. If the vehicle lines are interfering with the strut tower brace, gently massage the lines downwards/away from the strut tower brace until adequate clearance is achieved.