



STRUT TOWER BRACE

(2008-2023 CHALLENGER; EXCL 6.2L, & Shaker Hoods)
(2015-2023 CHARGER)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) Strut Tower Brace
- (6) M8 x 1.25 Flange Nuts

TOOLS REQUIRED

- 13mm Deep Socket
- Ratchet
- Floor Jack



STEP 1



Open the vehicle hood. Remove the OEM strut covers, if equipped. Remove the engine cover (5.7L). Remove (6) 13mm upper strut nuts.

STEP 2



Fit the strut tower brace to the vehicle strut studs. Once fitted, use the included (6) M8 flange nuts to secure the brace to the vehicle.

Note: If the strut studs do not align with the strut brace initially, use a floor jack and slightly lift the vehicle to relieve strut tension. Then, push/pull the strut studs to better align with the brace.



STEP 3



Torque the strut nuts evenly to 20 ft. lbs. Installation is now complete.

Note: Some vehicles have close A/C line and EVAP line clearance. If the vehicle lines are interfering with the strut tower brace, gently massage the lines downwards/away from the strut tower brace until adequate clearance is achieved.