



ABD-902 CATCH CAN INSTRUCTIONS

Included in your package is everything you need to install your catch can:

- Qty 1: Catch Can – This is assembled with the two chamber top and bottom with O-ring, 304 stainless mesh in bottom can reservoir (this stays in the bottom of the catch can and provides surface area for the oil to accumulate and settle to the bottom), aluminum mechanical filter between top and bottom, 2 barbed elbows, and mounting bracket
- QTY 1: 10 MM Allen cap mounting Screw and Star Lock Washer
- Qty 2: ½" I.D. PCV (fuel line) Hose (lengths dependant on order/application)
- QTY 1: ½" x ½" Barbed Coupler (Offset bracket only – non Hellcat, not needed for Hellcat)

Optional items (you don't need them, but they take the appearance to the next level):

- Qty 4: Decorative hose end fittings (3 small to use at the catch can elbows and coupler and 1 large to PCV barb)
- Qty 2: Colored hose braid

You can see an install video on a 6.4L here (note, this install is similar to the 5.7L and 6.2L Hellcat):

www.youtube.com/watch?v=kHDaUFOsq7c



Written instructions for the 6.2L Hellcat can be found here:

<https://americanbrotherdesigns.com/hellcat-catch-can-install/>



www.americanbrotherdesigns.com

Phone: 800-617-2120

sales@americanbrotherdesigns.com