



SIDE SKIRTS

(2008-2021 CHALLENGER)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Side Skirt
- (1) RH Side Skirt
- (1) Roll of 3M Tape
- (16) Black Self-Tapping Screws

TOOLS REQUIRED

N/A

SKU # 412521



STEP 1

Thoroughly clean the rocker panel.



STEP 2

Apply the supplied 3M tape to the edge of the side skirt.



STEP 3

Ensure the factory rocker panels are completely dry prior to installing the rocker panels. Test fit the panels for best fit prior to removing the tape backing. Once comfortable with the positioning of the rocker panels, remove the tape backing. Apply firm even pressure to the taped areas to ensure proper adhesion.

Optional: Use the supplied screws if needed.