



## Front and Rear LED Side Marker Lights Installation Guide

### 2015-2023 Charger

#### Front Side Marker Lights:

1. Turn the wheel to the side to gain additional clearance to the fender liner. Remove (1) 9/32 screw and (4) push clips securing the fender liner to the bumper.
2. Peel the fender liner back to gain access to the back of the side marker light. Remove (2) T25 Torx screws from the back of the side marker housing.
3. Remove and unplug the side marker light from the vehicle.
4. Using the T25 Torx screws, pre-thread the LED side marker light housing to ensure ease of installation.
5. Install the LED side marker light into the vehicle following steps 1-3 in reverse order. Repeat this procedure to the opposite side. Front installation is now complete.

#### Rear Side Marker Lights:

1. Remove (2) push clips securing the fender liner to the rear bumper.
2. Peel back the fender liner to gain access to the back side of the marker light. Remove (2) T25 Torx screws from the back side of the side marker housing.
3. Remove and unplug the side marker light from the vehicle.
4. Using the T25 Torx screws, pre-thread the LED side marker light housing to ensure ease of installation.

5. Install the LED side marker light into the vehicle following steps 1-3 in reverse order.  
Repeat this procedure to the opposite side. Rear installation is now complete.