



## advanced FLOW engineering

### Instruction Manual P/N: 46-39110

#### 95mm Throttle Body for GM V8-6.2L LT1, LT2, LT4, L86, L87

Camaro SS	2016-2024	Escalade ESV	2015-2021
Camaro ZL1	2017-2024	Sierra 1500	2014-2021
Corvette	2014-2025	Silverado 1500	2014-2021
Corvette Z06	2015-2019	Suburban	2019-2021
CT5-V Blackwing	2022-2025	Tahoe	2018-2021
CTS-V	2016-2019	Yukon	2015-2021
Escalade	2015-2021	Yukon XL	2015-2021



Qty.	Part Description
1	95mm Throttle Body
1	Throttle Body Adaptor, 87mm to 95mm
1	Throttle Body O-Ring Gasket

- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- For technical support please call 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Ensure that your vehicle is cooled off before proceeding.
- Retain factory parts for future use.

1. Disconnect the negative battery terminal.
2. Remove the air intake tube from the vehicle following the manufacturer's recommended procedure.
3. Disconnect the electrical connector from the factory throttle body.
4. Remove the four (4) screws securing the factory throttle body.
5. Carefully remove the factory throttle body from the intake manifold.
6. Clean the gasket surface on the intake manifold. Replace the gasket if necessary (*gasket not supplied*).
7. Install the supplied aFe Throttle Body Adapter with the included O-ring gasket, followed by the supplied aFe 95mm Throttle Body. Use the four (4) factory screws removed in Step 4. Torque to factory specifications: 10 Nm (89 in-lbs).
8. Reconnect the electrical connector to the aFe 95mm Throttle Body.
9. Reinstall the air intake tube following the manufacturer's recommended procedure.
10. Reconnect the negative battery terminal.
11. Installation is now complete.

**NOTE: Check all screws, clamps, and connectors are secure after 100-200 miles**