



---

# MOLDED FRONT TRUNK LINER

(2021+ MUSTANG MACH-E)

---

## INSTALLATION INSTRUCTIONS

### CONTENTS

---

(1) Front Trunk Liner

### TOOLS REQUIRED

---

Vacuum Cleaner (Optional)



**STEP 1**

Empty all contents from front trunk. Vacuum the front trunk storage area, if desired.



**STEP 2**

Place the front storage liner into the front trunk storage area. Ensure the edges are properly fitted. Placing the liner in the sun before installation will assist in edge fitment.

Installation is now complete.