



BILLET FOOT REST PEDAL COVER

(2021+ MUSTANG MACH-E)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Billet Pedal Cover

TOOLS REQUIRED

Isopropyl Alcohol
Microfiber Cloth

STEP 1



Locate the foot rest in the foot well, and clean using isopropyl alcohol and a microfiber cloth. Allow the foot rest to fully dry.

STEP 2



Align the foot rest cover to the vehicle before peeling the red tape backing to familiarize the fitment on the vehicle. Once familiar, peel the red tape backing and adhere the cover to the vehicle. Apply firm pressure to ensure proper adhesion.

Installation is now complete.