



---

# ADHESIVE BACKED INTERIOR / EXTERIOR TRIM PANELS

---

INSTALLATION INSTRUCTIONS

## TOOLS REQUIRED

---

Isopropyl Alcohol  
Microfiber Cloth



---

**EXTERIOR  
TRIM PANELS**

Clean the application site using isopropyl alcohol to ensure all wax/grease is removed. Allow the time for the panel to flash dry. Test fit the part to familiarize yourself with how it fits. Then, remove the tape backing and press the trim onto the vehicle. Apply firm even pressure to ensure proper adhesion.



---

**INTERIOR  
TRIM PANELS**

Clean the application site using isopropyl alcohol to ensure all wax/grease is removed. Allow the time for the panel to flash dry. Test fit the part to familiarize yourself with how it fits. Then, remove the tape backing and press the trim onto the vehicle. Apply firm even pressure to ensure proper adhesion.