



6.1L/5.7L Hemi Plate Installation Instructions

We have put together a few install tips to help your install go smoothly. If you have any questions and require tech help please call our tech line at **866-648-7637**

STEP 1: Disconnect negative battery terminal.

STEP 2: Disconnect air temp sensor plug and throttle body control motor connector plug.

STEP 3: Loosen clamps on air intake tube at throttle body and air box. Remove tube.

STEP 4: Remove the four bolts that secure the throttle body to intake manifold.

STEP 5: Place the Nitrous Outlet plate between the throttle body and the intake manifold. When installing the vehicle specific plate system, you will place the pre-assembled solenoid bracket between the intake manifold and the Nitrous Outlet Plate. **See Photos** *For 5.7L hemi cars using the vehicle specific plate systems, an EGR delete will be required for proper installation.

STEP 6: Reinstall throttle body, nitrous plate, and solenoids bracket (if applicable). Attach this assembly with supplied longer bolts in the plate conversion box.

STEP 7: Reinstall the air intake tube to the throttle body and air box. Tighten clamps.

STEP 8: Reconnect the air temp sensor and the throttle body control motor connector plug. Reconnect the negative battery terminal.

Attention: This is a custom built product. Jetting may vary from application to application. We strongly suggest dyno tuning with a wide band O2 reading to make sure your air fuel is correct.

Thank you for Choosing Nitrous Outlet for all your nitrous needs & for trusting us to supply you with the quality parts and service you need!!!!

Nitro Dave

www.nitrousoutlet.com

