



COLD AIR INTAKE

(2016-2023+ CAMARO - 6.2L ; EXCLUDING ZL1)

INSTALLATION INSTRUCTIONS

CONTENTS


- (1) Air Filter
- (1) MAF Housing
- (1) Heat Shield
- (1) Heat Shield Bracket
- (1) Intake Tube
- (2) Couplers
- (4) Clamps
- (1) Weatherstripping
- (1) Sound Tube Plug
- (3) M6 Threaded Inserts
- (4) M6x1.00 x 15mm Flange Bolts
- (2) M6x1.00 x 20mm Bolts
- (6) M6 Lock Washers
- (6) M6 Flat Washers
- (1) M6 Lock Nut

TOOLS REQUIRED

- T-25 Torx Bit
- 10mm Socket/Wrench
- Ratchet
- Flathead Screwdriver
- Phillips Screwdriver


SKU # CC26400

STEP 1




Unplug the vehicle MAF sensor, and unclip the wiring harness from the vehicle air box.

STEP 2



Unplug the PCV from the intake tube. Then, remove the sound tube from the intake tube.


STEP 3

Loosen (1) 8mm clamp securing the intake tube to the throttle body.


STEP 4

Remove the intake tube from the throttle body, and firmly lift the air box to dislodge the mounts from the vehicle rubber grommets. Remove the original intake assembly from the vehicle. Set on a workable surface for disassembly.

Note: If the rubber grommets are removed with the air box, remove the rubber grommets from the air box and re-install the grommets into the vehicle holes.

STEP 5


Fit the (3) M6 threaded inserts into the original air box rubber grommets.

STEP 6

Secure the rear of the heat shield to the previously installed threaded inserts using (2) M6 x 15mm Flange bolts, (2) M6 lock washers, and (2) M6 flat washers.

STEP 7

Secure the included heat shield mounting bracket to the heat shield using (1) M6 x 15mm flange bolt, (1) M6 lock washer, (2) M6 flat washers, and (1) M6 nut. Then, secure the mounting bracket to the previously placed threaded insert using (1) M6 flange bolt, (1) M6 lock washer, and (1) M6 flat washer.

STEP 8

Transfer the vehicle MAF sensor from the original intake tube to the new intake tube MAF housing. Secure the MAF sensor to the new housing using the included (2) Phillips bolts.

Note: The MAF sensor is directional and can only be installed in one direction.

STEP 9

Secure the MAF housing to the intake heat shield using (2) M6 x 20mm Hex bolts, (2) M6 lock washers, and (2) M6 flat washers into the MAF housing threaded inserts.

STEP 10

Secure the air filter to the previously installed MAF housing using the included air filter clamp.

**STEP 11**

Install (1) coupler and (2) clamps to the MAF housing. Then, install (1) coupler and (2) clamps to the intake tube. Then, fit the intake tube to the MAF housing and throttle body. Ensure both couplers are properly fitted, and tighten the clamps to secure the intake tube into place.

**STEP 12**

Press the PCV hose onto the intake tube fitting.

Use the included rubber grommet to cap off the sound tube.



STEP 13

Plug in the MAF sensor harness into the MAF sensor. Route the harness away from any hot/moving components. Ensure all clamps are secure. Route the included weatherstripping around the perimeter of the heat shield, trim to fit as necessary.

Installation is now complete.